

List1

```
[ 76.118128] hm2: loading Mesa HostMot2 driver version 0.15
[ 76.123271] hm2_pci: loading Mesa AnyIO HostMot2 driver version 0.6
[ 76.125487] hm2_pci: discovered 5i20 at 0000:04:00.0
[ 76.343040] hm2/hm2_5i20.0: 72 I/O Pins used:
[ 76.343052] hm2/hm2_5i20.0: IO Pin 000 (P2-01): Encoder #1, pin B (Input)
[ 76.343060] hm2/hm2_5i20.0: IO Pin 001 (P2-03): Encoder #1, pin A (Input)
[ 76.343067] hm2/hm2_5i20.0: IO Pin 002 (P2-05): Encoder #0, pin B (Input)
[ 76.343074] hm2/hm2_5i20.0: IO Pin 003 (P2-07): Encoder #0, pin A (Input)
[ 76.343081] hm2/hm2_5i20.0: IO Pin 004 (P2-09): Encoder #1, pin Index (Input)
[ 76.343089] hm2/hm2_5i20.0: IO Pin 005 (P2-11): Encoder #0, pin Index (Input)
[ 76.343096] hm2/hm2_5i20.0: IO Pin 006 (P2-13): PWMGen #1, pin Out0 (PWM or Up) (Output)
[ 76.343104] hm2/hm2_5i20.0: IO Pin 007 (P2-15): PWMGen #0, pin Out0 (PWM or Up) (Output)
[ 76.343112] hm2/hm2_5i20.0: IO Pin 008 (P2-17): PWMGen #1, pin Out1 (Dir or Down) (Output)
[ 76.343120] hm2/hm2_5i20.0: IO Pin 009 (P2-19): PWMGen #0, pin Out1 (Dir or Down) (Output)
[ 76.343128] hm2/hm2_5i20.0: IO Pin 010 (P2-21): PWMGen #1, pin Not-Enable (Output)
[ 76.343135] hm2/hm2_5i20.0: IO Pin 011 (P2-23): PWMGen #0, pin Not-Enable (Output)
[ 76.343143] hm2/hm2_5i20.0: IO Pin 012 (P2-25): Encoder #3, pin B (Input)
[ 76.343150] hm2/hm2_5i20.0: IO Pin 013 (P2-27): Encoder #3, pin A (Input)
[ 76.343157] hm2/hm2_5i20.0: IO Pin 014 (P2-29): Encoder #2, pin B (Input)
[ 76.343164] hm2/hm2_5i20.0: IO Pin 015 (P2-31): Encoder #2, pin A (Input)
[ 76.343171] hm2/hm2_5i20.0: IO Pin 016 (P2-33): Encoder #3, pin Index (Input)
[ 76.343179] hm2/hm2_5i20.0: IO Pin 017 (P2-35): Encoder #2, pin Index (Input)
[ 76.343186] hm2/hm2_5i20.0: IO Pin 018 (P2-37): PWMGen #3, pin Out0 (PWM or Up) (Output)
[ 76.343194] hm2/hm2_5i20.0: IO Pin 019 (P2-39): PWMGen #2, pin Out0 (PWM or Up) (Output)
[ 76.343202] hm2/hm2_5i20.0: IO Pin 020 (P2-41): PWMGen #3, pin Out1 (Dir or Down) (Output)
[ 76.343210] hm2/hm2_5i20.0: IO Pin 021 (P2-43): PWMGen #2, pin Out1 (Dir or Down) (Output)
[ 76.343217] hm2/hm2_5i20.0: IO Pin 022 (P2-45): PWMGen #3, pin Not-Enable (Output)
[ 76.343225] hm2/hm2_5i20.0: IO Pin 023 (P2-47): PWMGen #2, pin Not-Enable (Output)
[ 76.343231] hm2/hm2_5i20.0: IO Pin 024 (P3-01): IOPort
[ 76.343237] hm2/hm2_5i20.0: IO Pin 025 (P3-03): IOPort
[ 76.343243] hm2/hm2_5i20.0: IO Pin 026 (P3-05): IOPort
[ 76.343248] hm2/hm2_5i20.0: IO Pin 027 (P3-07): IOPort
[ 76.343254] hm2/hm2_5i20.0: IO Pin 028 (P3-09): IOPort
[ 76.343259] hm2/hm2_5i20.0: IO Pin 029 (P3-11): IOPort
[ 76.343265] hm2/hm2_5i20.0: IO Pin 030 (P3-13): IOPort
[ 76.343271] hm2/hm2_5i20.0: IO Pin 031 (P3-15): IOPort
[ 76.343276] hm2/hm2_5i20.0: IO Pin 032 (P3-17): IOPort
[ 76.343282] hm2/hm2_5i20.0: IO Pin 033 (P3-19): IOPort
[ 76.343287] hm2/hm2_5i20.0: IO Pin 034 (P3-21): IOPort
[ 76.343293] hm2/hm2_5i20.0: IO Pin 035 (P3-23): IOPort
[ 76.343298] hm2/hm2_5i20.0: IO Pin 036 (P3-25): IOPort
[ 76.343304] hm2/hm2_5i20.0: IO Pin 037 (P3-27): IOPort
[ 76.343310] hm2/hm2_5i20.0: IO Pin 038 (P3-29): IOPort
[ 76.343315] hm2/hm2_5i20.0: IO Pin 039 (P3-31): IOPort
[ 76.343321] hm2/hm2_5i20.0: IO Pin 040 (P3-33): IOPort
[ 76.343326] hm2/hm2_5i20.0: IO Pin 041 (P3-35): IOPort
[ 76.343332] hm2/hm2_5i20.0: IO Pin 042 (P3-37): IOPort
[ 76.343337] hm2/hm2_5i20.0: IO Pin 043 (P3-39): IOPort
[ 76.343343] hm2/hm2_5i20.0: IO Pin 044 (P3-41): IOPort
[ 76.343349] hm2/hm2_5i20.0: IO Pin 045 (P3-43): IOPort
[ 76.343354] hm2/hm2_5i20.0: IO Pin 046 (P3-45): IOPort
[ 76.343360] hm2/hm2_5i20.0: IO Pin 047 (P3-47): IOPort
[ 76.343365] hm2/hm2_5i20.0: IO Pin 048 (P4-01): IOPort
```

List1

[76.343371] hm2/hm2_5i20.0: IO Pin 049 (P4-03): IOPort
[76.343376] hm2/hm2_5i20.0: IO Pin 050 (P4-05): IOPort
[76.343382] hm2/hm2_5i20.0: IO Pin 051 (P4-07): IOPort
[76.343388] hm2/hm2_5i20.0: IO Pin 052 (P4-09): IOPort
[76.343393] hm2/hm2_5i20.0: IO Pin 053 (P4-11): IOPort
[76.343399] hm2/hm2_5i20.0: IO Pin 054 (P4-13): IOPort
[76.343404] hm2/hm2_5i20.0: IO Pin 055 (P4-15): IOPort
[76.343410] hm2/hm2_5i20.0: IO Pin 056 (P4-17): IOPort
[76.343415] hm2/hm2_5i20.0: IO Pin 057 (P4-19): IOPort
[76.343421] hm2/hm2_5i20.0: IO Pin 058 (P4-21): IOPort
[76.343427] hm2/hm2_5i20.0: IO Pin 059 (P4-23): IOPort
[76.343432] hm2/hm2_5i20.0: IO Pin 060 (P4-25): IOPort
[76.343438] hm2/hm2_5i20.0: IO Pin 061 (P4-27): IOPort
[76.343443] hm2/hm2_5i20.0: IO Pin 062 (P4-29): IOPort
[76.343449] hm2/hm2_5i20.0: IO Pin 063 (P4-31): IOPort
[76.343454] hm2/hm2_5i20.0: IO Pin 064 (P4-33): IOPort
[76.343460] hm2/hm2_5i20.0: IO Pin 065 (P4-35): IOPort
[76.343466] hm2/hm2_5i20.0: IO Pin 066 (P4-37): IOPort
[76.343471] hm2/hm2_5i20.0: IO Pin 067 (P4-39): IOPort
[76.343477] hm2/hm2_5i20.0: IO Pin 068 (P4-41): IOPort
[76.343482] hm2/hm2_5i20.0: IO Pin 069 (P4-43): IOPort
[76.343488] hm2/hm2_5i20.0: IO Pin 070 (P4-45): IOPort
[76.343493] hm2/hm2_5i20.0: IO Pin 071 (P4-47): IOPort